



SWOLLEN ATOMISER RUBBER CONE



Prolonged contact with the Intake product can cause the rubber cone to swell. When swollen this can loosen the fitting of the rubber cone to the atomiser.

It is good housekeeping to clean and dry the rubber cone and atomiser after use. And empty the intake tank of any remaining product.
(Hold atomiser in to waste container, select intake program, press and hold START for 3 seconds to initiate emptying process).



NOTE: do not leave fluid in the tank with the atomiser sat in the tank opening. Evaporation of the product will cause the rubber cone to swell.

New rubber cones are available through the accessory parts list.

